

2.7 Setup

```
Single channel mode
Selected ch's mode
Spectrum mode
Sound On/Off
Power to antenna
Select channels
▶Setup
```

```
▶Display contrast
Auto Power Off
Spectrum info bar
CCIR System
```

NOTE: On some models only one CCIR System is available. The **CCIR System** option in the **Setup** submenu is not present on those models.

2.8 Display contrast

```
▶Exit
Darker
Lighter
```

To adjust the contrast of the display, move the cursor to **Darker** or **Lighter** and repeatedly push the red **ON/MENU** button.

2.9 Auto power Off

```
Never
▶After 1 min
After 5 min
After 15 min
After 30 min
```

The unit can be automatically switched off after **1 min**, **5 min**, **15 min** or **30 min**. The factory setting of this function is **1 min**. The unit will only switch off if you have not touched any buttons during the selected time. To disable **Auto power Off** set it to **Never**.

Tip: Set **Auto power Off** to **1 min** when you are not using the unit and it is kept in for example in a bag. Otherwise the battery may go empty if the red **ON/MENU** button is accidentally pressed down and the unit turns on.

2.10 Spectrum info bar

```
▶Always visible
Hide after 2 sec
Hide after 4 sec
Hide after 8 sec
```

Select if You want the information in the **Spectrum mode** to be **Always visible** or **hidden** after **2**, **4** or **8** seconds when You have not touched the **UP** or **OFF/DOWN** buttons.

